

Universal instrument set TRS-S



Insertion tools

ITE



ITEL



IT



ITL



ITHE



Hex drivers

SD




SDL



Removal tool

SR





Pilot drills



DB2020



D2020

Form drills



D2516



D4316



D2816



D4616



D3216



D5016



D3616



D5316



D4016



D5506

Torque wrench TW50



Direct wrench DW



Direction indicator DIR

